# STONHARD

# **PRODUCT DESCRIPTION**

TecTop UF is a nominal 1.5 mm thick resurfacing system with a decorative stain resistant surface. The color flake layer provides unlimited color options and is sealed with a urethane sealer to form a seamless, stain resistant surface that can be installed quickly. It is comprised of:

#### TecTop Undercoat

A two-component, high solids, epoxy bonding coat. A colored coat that accepts the flakes.

#### Stontec Flakes

Brightly colored flakes.

#### Stonseal CA7

A two-component, UV resistant, aliphatic polyaspartic urethane sealer.

## PACKAGING

TecTop UF is packaged in units for easy handling. Each Unit consists of:

#### TecTop Undercoat

0.5 Carton of pigmented undercoat containing: 4 foil bags of Amine 4 poly bags of Resin

#### Stontec Flakes

0.67 individual boxes of small (1/16 in.) colored flakes or

0.50 individual boxes of large (1/4 in.) colored flakes

#### Stonseal CA7

I carton containing: 2 foil bags of Isocyanate (2) 4 liter cans of a Amine

## COVERAGE

Each unit of TecTop UF will cover approximately 18.6 m<sup>2</sup> of surface at a nominal 1.5 mm thickness.

## **STORAGE CONDITIONS**

Store all components of TecTop UF between 16 to 30°C in a dry area. Avoid excessive heat and do not freeze. Shelf life is 3 years for the undercoat and one year for Stonseal CA7, in the original unopened container.

#### COLOR

TecTop UF is available in twelve standard colors in small (1/16 in.) or large (1/4 in.) sized flakes. Refer to the Stontec Color Sheet. Custom colors are available upon request.

Note: Micro (1/32 in.) flakes are available upon special request.

#### SUBSTRATE

TecTop UF is designed as a resurfacing layer for an existing floor system or to be combined with one of Stonhard's mortar systems. It is not designed to be installed directly on a concrete substrate. Typically, this system will be installed over an existing epoxy or urethane base floor system. For questions regarding an appropriate substrate, contact Stonhard's Technical Service Department.

## SUBSTRATE PREPARATION

Proper preparation is critical to ensure an adequate bond and system performance. The existing system must be dry and properly prepared utilizing mechanical methods. Questions regarding substrate preparation should be directed to your local Stonhard representative or Technical Service.

#### PRIMING

The use of a primer prior to the application of the TecTop system is typically not required. However, if the existing system is very porous, priming with HT Primer will minimize undercoat soak-in and result in a better application. The HT Primer must be allowed to cure prior to overlaying with the TecTop Undercoat. Questions regarding priming prior to the application of the TecTop should be directed to Stonhard's Technical Service Department

**TEC**TOP<sup>®</sup>UF

Abrasion Resistance0.03 gm max. weight loss
(ASTM D-4060, CS-17)
Cure Rate12 hours for foot traffic
(@ 25°C)24 hours for normal operations
FlammabilityClass 1
(ASTM E-648)
VOC Content TecTop U/C - 30 g/I
(ASTM D-2369, Method E) Stonseal CA7 - 100 g/l

Note: The above physical properties were measured in accordance with the referenced standards. Samples of the actual floor system, including binder and filler, were used as test specimens. All sample preparation and testing is conducted in a laboratory environment, values obtained on field applied materials may vary and certain test methods can only be conducted on lab made test coupons.

# MIXING

- Proper mixing is critical for the products to exhibit the proper application properties, cure properties and ultimate physical properties.
- Mechanical mixing is required for all components.
- See TecTop UF Directions for further details.

# APPLYING

- DO NOT attempt to install material if the temperatures of the TecTop UF components are not within 5 to 30°C. The cure time and application properties of the material are affected by temperature and severely affected by humidity levels.
- The undercoat is mixed, applied to the floor and broadcasted to refusal with Stontec Flakes. The undercoat is allowed to cure and excess flake is removed.
- Stonseal CA7 is mixed, applied to the floor and allowed to cure. The floor is lightly sanded and vacuumed.
- A second Stonseal CA7 is applied to the floor and allowed to cure.
- Refer to the TecTop UF Directions for further detail.

# NOTES

- Procedures for maintenance of the flooring system during operations are described in the Stonkleen Floor Cleaning Procedures Brochure.
- Specific information regarding chemical resistance is available in the Stontec Chemical Resistance Guide.
- Safety Data Sheets for TecTop UF are available on line at www.stonhard.com under Products or upon request.
- A staff of technical service engineers is available to assist with installation or to answer questions related to Stonhard flooring products.
- Requests for technical service or literature can be made through local sales representatives and offices, or corporate offices located worldwide.
- The appearance of all floor, wall and lining systems will change over time due to normal wear, abrasion, traffic and cleaning. Generally, high gloss coatings are subject to a reduction in gloss, while matte finish coatings can increase in gloss level under normal operating conditions.
- Surface texture of resinous flooring surfaces can change over time as a result of wear and surface contaminants. Surfaces should be cleaned regularly and deep cleaned periodically to ensure no contaminant buildup occurs. Surfaces should be periodicall inspected to ensure they are performing as expected and may require traction-enhancing maintenance to ensure they continue to meet expectations for the particular area and conditions of use.

#### IMPORTANT:

Stonhard believes the information contained here to be true and accurate as of the date of publication. Stonhard makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

Rev.6/19 © 2019 Stonhard www.Stonhard.com



European Offices:

Belgium France Poland +32 674 93 710 +33 160 064 419 +48 422 112 768

Spain Portugal United Kindom East Europe +34 933 623 785 Germa +351 227 535 642 The No +44 1925 649 458 Italy +48 422 112 768

35 Germany 12 The Netherlands 58 Italy +49 240 541 740 +31 165 585 200 +39 022 53 751